


# QwikFoot™




## INSTALLATION GUIDE NISSAN




Questions? Please contact Roll-N-Lock Customer Service @ 954-785-7655 or [www.rollnlock.com](http://www.rollnlock.com)  
A-751-INSTQF809 RB 06-23-14 APP:LG

### PARTS LIST

Item	Part Name	Qty.	Item	Part Name	Qty.	Item	Part Name	Qty.
A	QwikFoot Bracket	4	F	Front QwikFoot Sleeve	2	K	1/4-20 Nut	4
B	Front Bed Clamp	2	G	5/16-18 Socket Screw	8	L	QwikFoot Tree Clip	16
C	Back Right Bed Clamp	1	H	5/16" Lock Washer	8	M	5/16" Allen Wrench	1
D	Back Left Bed Clamp	1	I	1/4-20 Socket Screw	4	N	1/4" Allen Wrench	1
E	Back QwikFoot Sleeve	2	J	1/4" Lock Washer	4			








### TOOLS NEEDED




1 LHS = RHS


x 2




2 LHS = RHS




3 LHS = RHS




4 LHS = RHS




5 LHS = RHS




6 LHS = RHS



7



8 LHS = RHS



9

INSTALL  
ROLL•N•LOCK:



**NISSAN**



NISSAN DOUBLE CAB




NISSAN KING CAB

**ROLL-N-LOCK TONNEAU COVER**

<b>GB</b>	ROLL-N-LOCK Tonneau Cover	<b>NO</b>	ROLL-N-LOCK Tonneau Cover
<b>BG</b>	ROLL и LOCK Tonneau Cover	<b>PL</b>	ROLKI N-LOCK Tonneau Cover
<b>HR</b>	Roll i LOCK pokrovom	<b>PT</b>	ROLO E FECHADURA COBERTURA DE TONNEAU
<b>CZ</b>	ROLL a LOCK kryt zavazadlového prostoru	<b>RO</b>	ROLL și de a bloca Tonneau Cover
<b>DK</b>	ROLL-N-LOCK Tonneau Cover	<b>RU</b>	РУЛОН И ПОКРЫТИЕ ТОННЕАУ ЗАМКА
<b>NL</b>	BROODJE-N-SLOT de Dekking van Tonneau	<b>SK</b>	ROLL A LOCK kryt batožinového priestoru
<b>FI</b>	RO-N-LOCK Tonneau kansi	<b>SI</b>	ROLL IN LOCK Tonneau Cover
<b>FR</b>	ROULEAU ET LOCK Tonneau Cover	<b>ES</b>	RUEDA y la CERRADURA Tonneau Cubieta
<b>DE</b>	ROLLEN sie und SCHLOB Tonneau Kappe	<b>SE</b>	ROLL-N-LOCK Tonneau Täcker
<b>GR</b>	Κάλυψη Tonneau πόλος-υ-ΚΛΕΙΔΑΡΙΩΝ	<b>TR</b>	RULO-N-LOCK Tonneau Kapak
<b>HU</b>	ROLL és LOCK platófédél	<b>UA</b>	ROLL i замок кришки Tonneau
<b>IS</b>	Rúlla og Læssa Tonneau Kápa	<b>AR</b>	كاسا تونو لوك tonneau الله ... الخيين
<b>IT</b>	ROTOLO e SERRATURA Tonneau Coperta	<b>IL</b>	רול-נ-לוק-טוןאו שער של Tonneau

10 LHS = RHS



11 LHS = RHS

